

# **PRESSURE DIFFERENTIAL**

(AUTO RESET PRESSURE CONTROLS)

<b>UPPER SET POINTS (PSI)</b>	<b>DIFFERENTIAL (PSI)</b>	<b>MIN. TOLERANCE (PSI)</b>
VAC - 18	50 - 70	*
18 - 50	40 - 65	5
51 - 120	50 - 75	7
121 - 250	60 - 75	10
251 - 350	60 - 75	10
351 - 500	65 - 80	10
501 - 750	70 - 80	15

Please contact INNOVATIVZ for pressure settings not listed above

